§ 125.219

- (b) No passenger or crewmember may smoke while any "No Smoking" sign is lighted nor may any passenger or crewmember smoke in any lavatory.
- (c) Each passenger required by §125.211(b) to occupy a seat or berth shall fasten his or her safety belt about him or her and keep it fastened while any "Fasten Seat Belt" sign is lighted.
- (d) Each passenger shall comply with instructions given him or her by crewmembers regarding compliance with paragraphs (b) and (c) of this section.

[Doc. No. 26142, 57 FR 42675, Sept. 15, 1992]

§ 125.219 Oxygen for medical use by passengers.

- (a) Except as provided in paragraphs (d) and (e) of this section, no certificate holder may allow the carriage or operation of equipment for the storage, generation or dispensing of medical oxygen unless the unit to be carried is constructed so that all valves, fittings, and gauges are protected from damage during that carriage or operation and unless the following conditions are met:
 - (1) The equipment must be—
- (i) Of an approved type or in conformity with the manufacturing, packaging, marking, labeling, and maintenance requirements of title 49 CFR parts 171, 172, and 173, except §173.24(a)(1);
- (ii) When owned by the certificate holder, maintained under the certificate holder's approved maintenance program;
- (iii) Free of flammable contaminants on all exterior surfaces; and
 - (iv) Appropriately secured.
- (2) When the oxygen is stored in the form of a liquid, the equipment must have been under the certificate holder's approved maintenance program since its purchase new or since the storage container was last purged.
- (3) When the oxygen is stored in the form of a compressed gas as defined in title 49 CFR 173.300(a)—
- (i) When owned by the certificate holder, it must be maintained under its approved maintenance program; and
- (ii) The pressure in any oxygen cylinder must not exceed the rated cylinder pressure.

- (4) The pilot in command must be advised when the equipment is on board and when it is intended to be used.
- (5) The equipment must be stowed, and each person using the equipment must be seated so as not to restrict access to or use of any required emergency or regular exit or of the aisle in the passenger compartment.
- (b) When oxygen is being used, no person may smoke and no certificate holder may allow any person to smoke within 10 feet of oxygen storage and dispensing equipment carried under paragraph (a) of this section.
- (c) No certificate holder may allow any person other than a person trained in the use of medical oxygen equipment to connect or disconnect oxygen bottles or any other ancillary component while any passenger is aboard the airplane.
- (d) Paragraph (a)(1)(i) of this section does not apply when that equipment is furnished by a professional or medical emergency service for use on board an airplane in a medical emergency when no other practical means of transportation (including any other properly equipped certificate holder) is reasonably available and the person carried under the medical emergency is accompanied by a person trained in the use of medical oxygen.
- (e) Each certificate holder who, under the authority of paragraph (d) of this section, deviates from paragraph (a)(1)(i) of this section under a medical emergency shall, within 10 days, excluding Saturdays, Sundays, and Federal holidays, after the deviation, send to the FAA Flight Standards district office charged with the overall inspection of the certificate holder a complete report of the operation involved, including a description of the deviation and the reasons for it.

§ 125.221 Icing conditions: Operating limitations.

(a) No pilot may take off an airplane that has frost, ice, or snow adhering to any propeller, windshield, wing, stabilizing or control surface, to a powerplant installation, or to an airspeed, altimeter, rate of climb, or flight attitude instrument system, except under the follow conditions:

- (1) Takeoffs may be made with frost adhering to the wings, or stabilizing or control surfaces, if the frost has been polished to make it smooth.
- (2) Takeoffs may be made with frost under the wing in the area of the fuel tanks if authorized by the Administrator.
- (b) No certificate holder may authorize an airplane to take off and no pilot may take off an airplane any time conditions are such that frost, ice, or snow may reasonably be expected to adhere to the airplane unless the pilot has completed the testing required under § 125.287(a)(9) and unless one of the following requirements is met:
- (1) A pretakeoff contamination check, that has been established by the certificate holder and approved by the Administrator for the specific airplane type, has been completed within 5 minutes prior to beginning takeoff. A pretakeoff contamination check is a check to make sure the wings and control surfaces are free of frost, ice, or snow.
- (2) The certificate holder has an approved alternative procedure and under that procedure the airplane is determined to be free of frost, ice, or snow.
- (3) The certificate holder has an approved deicing/anti-icing program that complies with §121.629(c) of this chapter and the takeoff complies with that program.
- (c) Except for an airplane that has ice protection provisions that meet appendix C of this part or those for transport category airplane type certification, no pilot may fly—
- (1) Under IFR into known or forecast light or moderate icing conditions; or
- (2) Under VFR into known light or moderate icing conditions, unless the airplane has functioning deicing or anti-icing equipment protecting each propeller, windshield, wing, stabilizing or control surface, and each airspeed, altimeter, rate of climb, or flight attitude instrument system.
- (d) Except for an airplane that has ice protection provisions that meet appendix C of this part or those for transport category airplane type certification, no pilot may fly an airplane into known or forecast severe icing conditions.
- (e) If current weather reports and briefing information relied upon by the

pilot in command indicate that the forecast icing condition that would otherwise prohibit the flight will not be encountered during the flight because of changed weather conditions since the forecast, the restrictions in paragraphs (b) and (c) of this section based on forecast conditions do not apply.

[45 FR 67235, Oct. 9, 1980, as amended by Amdt. 125–18, 58 FR 69629, Dec. 30, 1993]

EFFECTIVE DATE NOTE: At 74 FR 62696, Dec. 1, 2009, §125.221 was amended by revising paragraphs (a) and (c), effective Feb. 1, 2010. For the convenience of the user, the revised text is set forth as follows:

§ 125.221 Icing conditions: Operating limitations.

(a) No pilot may take off an airplane that has frost, ice, or snow adhering to any propeller, windshield, stabilizing or control surface; to a powerplant installation; or to an airspeed, altimeter, rate of climb, flight attitude instrument system, or wing, except that takeoffs may be made with frost under the wing in the area of the fuel tanks if authorized by the FAA.

* * * * * *

- (c) No pilot may fly under IFR into known or forecast light or moderate icing conditions, or under VFR into known light or moderate icing conditions, unless—
- (1) The aircraft has functioning deicing or anti-icing equipment protecting each propeller, windshield, wing, stabilizing or control surface, and each airspeed, altimeter, rate of climb, or flight attitude instrument system;
- (2) The airplane has ice protection provisions that meet appendix C of this part; or
- (3) The airplane meets transport category airplane type certification provisions, including the requirements for certification for flight in icing conditions.

§ 125.223 Airborne weather radar equipment requirements.

- (a) No person may operate an airplane governed by this part in passenger-carrying operations unless approved airborne weather radar equipment is installed in the airplane.
- (b) No person may begin a flight under IFR or night VFR conditions when current weather reports indicate that thunderstorms, or other potentially hazardous weather conditions